

# **Uterine Fibroid**

(revised 12/2009)

- Use power injector
- Have patient empty bladder before scanning
- Contrast dosage 0.1mmol/kg

## **1. SCOUT**

**2. AXIAL T1 TSE (Cover entire pelvis)**

**3. AXIAL T2 TSE (Cover entire pelvis)**

**4. SAGITTAL T2 TSE non-BH (high resolution, 4mm cuts, small FOV)**

**5. CORONAL T2 TSE non-BH (high resolution, small FOV)**

**6. SAGITTAL STIR**

**7. Pre-Gad AXIAL LAVA T1 BH**

**Give Gadolinium**

**8. Post-Gad SAGITTAL LAVA T1 BH (45 sec delay)**

**9. Post-Gad AXIAL LAVA T1 BH (90 sec)**

**10. Post-Gad CORONAL LAVA T1 BH (3 min)**