

ELBOW ARTHROGRAM

NOTES

- 1. Axial imaging, start below the Radial Tuberosity to above the Olecranon fossa**
- 2. Coronal imaging, start below the Triceps tendon insertion (Olecranon) to the biceps tendon.**
- 3. Sagittal imaging, adjust slices perpendicular to the humeral epicondyles. Scan through epicondyles**
- 4. Use extremity coil with patient in "superman position", otherwise use flex coil with patient positioned so the elbow is as close to isocenter as possible.**
- 5. Place arm straight in a supinated position**

- 1. Coronal T1 SE FS**
- 2. Coronal PD Hybrid fs**
- 3. Coronal MPGR**
- 4. Axial T1 Non FS**
- 5. Axial PD Hybrid fs**
- 6. Sagittal PD Hybrid fs**
- 7. Coronal STIR**