

SHOULDER

1. Immobilize the arm with sandbags or straps.
2. Use saturation bands where appropriate.
3. Keep the phase encoding in the direction with the least motion.
4. Use 4mm slice thickness with a 1mm gap.

Revised 1/10

(1) SCOUT

(2) AXIAL PD Hybrid fs

(3) CORONAL OBLIQUE T2 fs (TE 50-60)

(4) CORONAL OBLIQUE T2 non fs (TE 50-60)

(5) SAGITTAL OBLIQUE PD Hybrid fs

(6) SAGITTAL OBLIQUE T1 high res