

SHOULDER ARTHROGRAM

1. Immobilize the arm with sandbags or straps.
 2. Use saturation bands where appropriate.
 3. Keep the phase encoding in the direction with the least motion.
 4. Use 4mm slice thickness with a 1mm gap.
 5. All sequences before ABER are in external rotation
- Revised 10/08

(1) SCOUT

(2) AXIAL PD Hybrid fs

(3) Ax T1 fs

(4) CORONAL OBLIQUE T1 fs

(5) CORONAL OBLIQUE T2 fs (TE 50-60)

(6) SAGITTAL OBLIQUE T1 non fs

(7) SAGITTAL OBLIQUE PD Hybrid fs

ABER:

(8) Sag Oblique MPGR

(9) Sag Oblique PD Hybrid fs